

CRUISER GARAGE



AC Drain Extension Kit (ADEK) for 2010-2022 4Runner / GX460

Thank you for purchasing from Cruiser Garage! If you have any questions please contact us at info@cruiser-garage.com

QTY	Parts Included
1	Fitting
1	Tubing
3	Zip-Ties

Tools Required: Wire Cutters (to cut zip-tie excess)

1. Insert elbow in one end of the provided tubing.
2. Locate the factory AC drain line on the right side of the firewall.



Engine Bay (Fender Liner Removed):

3. Insert fitting into the opening of the factory drain line (moving fitting side to side helps).
4. Decide how you would like to run the line. We chose to run it this way (Fig.2, 3), but there are a few other ways as well. Please remember to not overtighten the zip-ties and pinch the line.



Fig.2:



Fig.3:

5. Secure the line with the zip-ties where needed. In our case, one regular zip-tie in the inner fender and one low-profile zip tie around the body mount was enough.
6. Cut excess off zip-ties. If required, cut excess off the end of the extension line. Done!

Thanks again for your purchase! We hope you enjoy it!